

Beam Loss Monitors



When energetic beam particles penetrates matter, secondary particles are emitted:

this can be e^- , γ , protons, neutrons, excited nuclei, fragmented nuclei...

⇒ Spontaneous radiation and permanent activation is produced.

⇒ Large variety of Beam Loss Monitors (**BLM**) depending on the application.

Protection: Sensitive devices e.g. super-conducting magnets to prevent quenching
(energy absorption by electronic stopping)

→ **interlock signal for fast beam abortion.**

Beam diagnostics: Alignment of the beam to prevent for activation

→ **optimal transmission to the target.**

Accelerator physics: **using these sensitive particle detectors.**

- Several devices are used, depending on particle rate and required time resolution
- Some applications for usage

Secondary Particle Production for Electron Beams



Processes for interaction of electrons

For $E_{kin} > 100$ MeV:

Bremsstrahlungs-photon dominated

$\Rightarrow \gamma \rightarrow e^+ + e^-$ or μ^\pm, π^\pm

\rightarrow electro-magnetic showers

\Rightarrow excitation of

nuclear giant resonances $E_{res} \approx 6$ MeV
via (γ, n) , (γ, p) or (γ, np)


\rightarrow fast neutrons emitted

\rightarrow neutrons: Long ranges in matter
due to lack of ele.-mag. interaction.

For $E_{kin} < 10$ MeV:

\Rightarrow only electronic stopping
(x-rays, slow e^-).


Energy loss for e^- in copper:




Secondary Particle Production for Proton Beams



Nuclear reaction probability:



Neutron yield per proton:




Thick target:

Penetration depth comparable to range
 → different types of nuclear reaction .

⇒ high rate of neutron with broad energy and angular distribution.

Various Beam Loss Monitors at the GSI-Synchrotron



Scintillators as Beam Loss Monitors



Plastics or liquids are used:

- detection of **charged particles** by electronic stopping
- detection of **neutrons** by elastic collisions n on p in plastics and fast p electronic stopping.

Scintillator + photo-multiplier:

counting (large PMT amplification)
or analog voltage ADC (low PMT amp.).




Radiation hardness:

plastics 1 Mrad = 10^4 Gy

liquid 10 Mrad = 10^5 Gy

Example: Analog pulses of plastic scintillator:

⇒ broad energy spectrum
due to many particle species and energies.



PIN-Diode (Solid State Detector) as BLM





Solid-state detector: Detection of charged particles.

Working principle


- About 10^4 e⁻-hole pairs are created by a Minimum Ionizing Particle (MIP).
- A coincidence of the two PIN reduces the background due to low energy photons.
- A counting module is used with threshold value comparator for alarming.

→ **small and cheap detector.**



Ionization Chamber as BLM

Detection of charged particles **only**.



Sealed tube Filled with Ar or N₂ gas:


- Creation of Ar⁺-e⁻ pairs, average energy $W=32$ eV/pair
- measurement of this current
- Slow time response due to 100 μs drift time of Ar⁺.

Per definition: direct measurement of dose.



BF₃ Proportional Tubes as BLM

Detection of neutrons **only**.




Physical processes of signal generation:

1. Slow down of fast neutrons by elastic collisions with p
2. Nuclear reaction inside BF₃ gas in tube:
$$^{10}\text{B} + \text{n} \rightarrow ^7\text{Li} + \alpha \text{ with } Q = 2.3 \text{ MeV.}$$
3. Electronic stopping of ⁷Li and α leads to signal.



Optical Fibers as BLM

Modification of fiber material is used as a measure of dose.




- several km long fibers (cheap due to use in tele-communication)
- 1 ns infra-red laser pulse
- OTDR (optical time domain reflector):
time and amplitude of reflected light \Rightarrow location of modification.

Comparison of different Types of BLMs



Different detectors are sensitive to various physical processes.

Example: Beam loss for 800 MeV/u O⁸⁺
with different BLMs at GSI-synchr.:



⇒ Linear behavior for all detectors

but quite different count rate:

$$r_{\text{IC}} < r_{\text{BF}_3} < r_{\text{liquid}} < r_{\text{plastic}}$$

Machine Protection Issues for BLM



Losses lead to permanent activation \Rightarrow maintenance is hampered
and to material heating (vacuum pipe, super-cond. magnet etc.) \Rightarrow destruction.

Types of losses:

- **Irregular** or fast losses by malfunction of devices (magnets, cavities etc.)
 - \rightarrow BLM as online control of the accelerator functionality and **interlock generation**.
- **Regular** or slow losses e.g. by lifetime limits or due to collimator
 - \rightarrow BLM used for alignment.

Demands for BLM:

- **High sensitivity** to detect behavior of beam halo e.g. at collimator
- **Large dynamic range:**
 - \rightarrow low signal during normal operation, but large signal in case of malfunction
 - \rightarrow detectable without changing the full-scale-range
e.g. scintillators from 10^2 1/s up to 10^7 1/s in counting mode.

Monitoring of loss rate in control room *and* as interlock signal for beam abortion.

Application: BLMs for Quench-Protection




Super-conducting magnets can be heated above critical temperature T_c by the lost beam
⇒ breakdown of super-conductivity = 'quenching'.

⇒ Interlock within 1 ms for beam abortion generated by BLM.

Position of detector at quadrupoles due to maximal beam size.

High energy particles leads to a shower in forward direction → Monte-Carlo simulation.


Example: LHC proton beam at 7 TeV: **shower maximum @ 11560cm**



Application: BLMs for optimal Tune Alignment



Example: Loss rate at a scraper inside the synchrotron as a function of the tune (i.e. small changes of quadrupole setting):



Beam blow-up by weak resonances can be avoided by proper tune value
→ very sensitive device for optimization.

Summary Beam Loss Monitors



Measurement of the lost fraction of the beam:

- detection of secondary products
- sensitive particle detectors are used outside the vacuum
- cheap installations used at many location

Used as interlock in all high current machines for protection.

Additionally used for sensitive 'loss studies'.

Depending on the application different types are used:

- **Scintillators:** sensitive, fast response, largest dynamics, not radiation hard
- **PIN diode:** insensitive, fast response, not radiation hard, cheap
- **Electron Multiplier:** medium sensitive, fast response, radiation hard
- **IC:** medium sensitive, slow response, radiation hard, cheap
- **BF₃ tube:** only neutrons, slow response, radiation hard, expensive
- **Optical fibers:** insensitive, very slow, radiation hard, very high spatial resolution.